



Notes

1. Handhole, **SC 521910**, shall be on field side of pole set flush with ground.
2. Secure 90 degree conduit bends, and end of flexible conduit, together with duct tape. Top of conduits shall extend no more than 6 inches up into handhole. Install 1/4" pull ropes with tags identifying conduit destinations.
3. Install flexible nonmetallic conduit, 1 1/4" maximum O.D., and extend up into pole for streetlight conductors. Install 1/4" pull rope from handhole to top of pole.
4. Select poles from **DTR 21.421** or **DTR 21.425**.

ORIGINAL	STREETLIGHT HANHOLE DIRECT-BURIED CONDUIT SYSTEM		
3/7/06			
APPROVED			
09/12/16 <i>Camp</i>	EVERSOURCE ENERGY	CONSTRUCTION STANDARD	DTR 21.427 1

